

Programming Cadillac CTS/SRX Radios **To receive XM Satellite Radio**

1. Using the Tech2 diagnostic tool, plug tool into OBDII connector and turn on the power for the Tech2
2. Hit the enter key, then select diagnostics
3. Select year of vehicle
4. Select type of vehicle—"Passenger car" for CTS; "MPV" for SRX
5. Select Cadillac
6. Select "D" body for CTS; Select "E" body for SRX
7. Select Body
8. Choose Radio type
9. Select Radio
10. Select Special Functions
11. Select Set Options
12. Select Optional Modules
13. Select Continue
14. If the star (*) icon is not next to "Digital Radio Receiver(DRR)", highlight line, and hit enter. The star icon will appear
15. Hit "save options"
16. Insert key and cycle ignition. Press the "Band" button on the radio until XM is displayed. Key may have to be cycled several times initially to recognize XM.